



# Cone Planter

## 1.1.1 Release Notes

---

### Required Software

- Mirus 4.6.3

### Required Actuator Firmware

- Version 6.22

### Supported Plugins

- GNSS Plugin version 2.1.1

### Fixed Issues

- Removed warning to recommend performance NMEA (CONE-76).
- Changed the default trip origin to offset position when collection enables (CONE-76).
- Mirus saves the actuator settings (CONE-75).
- Other minor improvements to work with Mirus 4.6.3.



tel: 435.753.1881 | web: [www.junipersys.com](http://www.junipersys.com)  
1132 W. 1700 N. Logan, UT 84321

---

PN 32263-00. Copyright © April 2024, Juniper Systems, Inc. All rights reserved. Information is subject to change without notice. GrainGage, Mirus, HarvestMaster, and Juniper Systems, Inc. logos are trademarks of Juniper Systems, Inc. Windows is a trademark of Microsoft Corporation in the United States and/or other countries.